

## INSTALLATION INSTRUCTIONS UPPER WIND DEFLECTORS

Copyright© 2001 by Big Bike Parts, Inc.  
No part of this instruction sheet may be  
reproduced without the written permission  
of Big Bike Parts, Inc.©

PART NO. 52-660U, 52-661U, 52-662U,  
52-664U, 52-665U, 52-666U, 52-667U,  
52-668U

HONDA GL1800 GOLD WING

Revised 03/23/07

ITEMS REQUIRED: 5MM ALLEN WRENCH      FLAT BLADE SCREWDRIVER

**NOTE:** PLACE THE RUBBER EDGING PIECE PROVIDED TO THE TOP OF THE WIND DEFLECTOR USING DOUBLE SIDED TAPE PROVIDED. MAKE SURE ALL SCREWS IN ASSEMBLY ARE SNUG. DO NOT OVER-TIGHTEN

### INSTALLATION:

1. USING FLAT BLADE SCREWDRIVER GENTLY PRY OFF THE LEFT FAIRING MOLDING (1A) STARTING FROM THE BOTTOM. TAKE CARE SO AS NOT TO BREAK OFF THE MOUNTING LEGS.
2. USING 5MM ALLEN WRENCH REMOVE THE TWO BOLTS (1B) THAT ARE LOCATED UNDER FAIRING MOLDING (1A).
3. PLACE THE WIND DEFLECTOR ASSEMBLY (2A) IN PLACE SO THAT THE MOUNTING BRACKETS FIT INTO THE GROOVE ON THE FAIRING.
4. SECURE INTO PLACE USING THE SOCKET HEAD BOLTS (1B) REMOVED IN STEP 2.
5. FOLLOW STEPS 1-4 FOR THE RIGHT SIDE.
6. REINSTALL FAIRING MOLDING (1A) ON BOTH SIDES PRESSING THE TOP IN FIRST AND GOING DOWN.

