



WORLD'S BEST  
**WINDSHIELDS AND ACCESSORIES**  
 MADE IN USA SINCE 1937

Keyword or Part Number

0 ITEMS - \$0.00

Filter product by:

Home | Product Overview | Cast Fender Tips and Speedo Cowls



## Cast Fender Tips and Speedo Cowls

From \$64.95 to \$164.95

This hallmark product of National Cycle (our legendary original designs patented in the 1940s) has been painstakingly refined for today's cruiser motorcycles. With our old-world casting methods, the shape and details that distinguish our Fender Tips really stand out.

You may also like our cast Speedometer Cowls. They not only add some stylish chrome to your bike, but they prevent instrument glare on your windshield when riding at night.



### Choose Your Vehicle to View Applications:

[VIEW APPLICATION CHART](#)

#### Cast Fender Tips and Speedo Cowls Applications

CLOSE

MODEL	YEARS	FRONT FENDER	REAR FENDER	SPEEDO COWL
<b>HONDA</b>				
VTX1800C (Specs 1-2-3)	2002-07	N/A	N7002	N/A
VTX1800R/S Retro (Specs 1-2-3)	2002-07	N7003	N7004	N/A
GL1500C Valkyrie/F6C	1997-03	N715*	N716	N/A
GL1500C Valkyrie/F6CT	2000-02	N715*	N716	N/A
VT1300CR Stateline	2010-16	N7052	N7053	N/A
VT1300CT Interstate	2010-16	N7052	N7053	TBA
VTX1300C	2004-09	N7009	N/A	N7801
VTX1300R/S/T	2003-09	N7005	N7006	N7801
VT1100C3 Aero	1997-02	N735	N736	N/A
VT1100C2 Sabre	2000-07	N733	N734	N/A
VT1100C2 Shadow A.C.E.	1995-99	N717*	N/A	N/A

VT1100C Shadow Spirit	1997-07	N731*	N732	N/A
VT1100 Shadow	1995-97	N731*	N732	N/A
VT1100 Shadow	1987-94	N731*	N732	N/A
VT750C2A/B Shadow Phantom/Black Spirit	2010-16	N/A	N/A	N7821
VT750C Shadow Aero	2004-09	N7015	N7016	N7821
VT750C Shadow Aero	2011-16	N7015	N7016	N7821
VT750CD Shadow A.C.E. Deluxe	1997-03	N733	N734	N/A
VT750C Shadow A.C.E.	1997-00	N733	N734	N/A
VT750C2 Shadow Spirit	2007-15	N/A	N/A	N7821
VT600C/CD Shadow VLX/DLX	1988-07	N725*	N726	N/A

#### **KAWASAKI**

VN2000	2004-09	N7011	N7012	N7811
VN2000 Classic/LT	2006-10	N7011	N7012	N7811
VN1700 Vulcan Nomad	2009-15	N7023	N7024	N7811
VN1700 Vulcan Voyager	2009-15	N7023	N7024	TBD
VN1700 Vulcan Classic/LT	2009-13	N7023	N7024	N7811
VN1600 Vulcan Classic	2003-08	N7013	N7014	N/A
VN1600 Vulcan Nomad	2005-08	N739FF/N739RF	N7014	N/A
VN1500G1 Vulcan Nomad	1998-04	N739FF/N739RF	N720	N/A
VN1500N Vulcan Classic	00-03/05-08	N724*	N720	N/A
VN1500T Vulcan	2006	N724*	N720	N/A
VN1500D/E Vulcan Classic	1996-04	N724*	N720	N/A
VN900B Vulcan 900 Classic/LT/SE	2006-16	N7021	N7022	N7810
VN900C Vulcan 900 Custom	2007-16	N7019	N7020	N7810
VN800B Vulcan Classic	1996-05	N719*	N721	N/A

#### **SUZUKI**

C109R/C190RT Boulevard/C1800R Intruder	2008-12	N7206	N7207	N/A
M109R Boulevard B.O.S.S.	2014-15	TBA	TBA	TBA
C90/C90T B.O.S.S. Boulevard	2014-15	N7017	N7018	N/A
C90/C90T Boulevard	2005-09	N7017	N7018	N/A
V1500LC Intruder LC	1998-04	N737	N738	N7820
S83 Boulevard	2005-08	N722*	N723	N/A
VS1400 Intruder	1987-04	N722*	N723	N/A
VS1400 Intruder (Flat Bar)	1987-89	N722*	N723	N/A
C50/Black/T/Limited Boulevard/C800 Intruder	2009-13	N/A	N/A	N7820
C50/Black/T/Limited Boulevard/C800 Intruder	2007-08	N7007	N7008	N7820
C50/Black/T/Limited Boulevard/C800 Intruder	2005-06	N7007	N7008	N7820
VL800 Intruder Volusia	2001-04	N7007	N7008	N7820
S50 Boulevard/S800 Intruder	2005-09	N722*	N/A	N/A
VS800 Intruder	1992-04	N722*	N/A	N/A
M50/M50 Black Boulevard/M800 Intruder	2010-15	TBD	TBD	TBD
VZ800 Marauder	1997-04	N/A	N730	N/A
VS750 Intruder	1988-91	N722*	N/A	N/A
VS700 Intruder	1985-87	N722*	N/A	N/A
VS600 Intruder	1995-98	N722*	N/A	N/A

#### **TRIUMPH**

Rocket III	2004-09	N7070	N7071	N/A
------------	---------	-------	-------	-----

#### **YAMAHA**

XV1700 Road Star/Silverado/Silverado S	2004-14	N7032	N7033	N/A
XV1600 Road Star/Wild Star/Silverado	1999-03	N7032	N7033	N/A
XV1600AS Road Star MM Limited	2000	N7032	N7033	N/A
XVS1300AT V Star 1300 Tourer	2007-15	N7030	N7031	N7830
XVS1300A V Star 1300	2007-15	N7030	N7031	N7830
XVS1100 V Star/DragStar Custom	1999-11	N727*	N/A	N/A
XVS650 V Star/DragStar Custom	1997-16	N727*	N/A	N/A

All Front Fender Tips are two-piece kits; Front of Front Fender/Rear of Front Fender (except where noted).

\* One-piece kit; Front of Front Fender only.

## DOWNLOADS

## LEARN MORE



Product Benefits



Quality Features



Hardware/Materials

Create the perfect fender treatment for your cruiser motorcycle! **National Cycle Cast Fender Tips** are an economical way to add that finishing touch to your customized bike.



National Cycle's Fender Tips are custom designed and clay modeled directly on the bike. They are sized for each model's front and rear fenders, so sizes will vary.



Our half-moon style **Speedometer Cowls** are also a perfect fit for your traditional tank console speedometer.

It will be hard to find accessories like these that will add so much to your bike at such a reasonable cost.

---

### NEED ASSISTANCE?

Contact Us  
Customer Support  
FAQ's

### ABOUT US

Who We Are  
Our ZTechnik® Brand

### NATIONAL CYCLE, INC.

2200 S. Maywood Drive  
Maywood, IL 60153-1745  
U.S.A.

P: 708-343-0400

F: 708-343-0625

E: [info@nationalcycle.com](mailto:info@nationalcycle.com)



Follow us on:

